

Xact® 640 Monitoring System



Multi-Metals Continuous Emissions Monitoring System (CEMS)

Description

Cooper Environmental's Xact® 640 system uses reel-to-reel filter tape sampling and nondestructive energy dispersive X-ray fluorescence (EDXRF) analysis to monitor stack HAP metal emissions. An isokinetic sub-sample of stack gas passes through the stilling chamber and is drawn through a chemically reactive filter tape. Vapor phase metals, including mercury (Hg), are deposited along with the particulate matter (PM) on the filter tape.

The deposit is automatically advanced and analyzed by XRF for selected metals as the next sample is being collected. Sampling and analysis are performed continuously and simultaneously, except during advancement of the tape (~20 sec) and during daily-automated quality assurance checks.

In 2007, through its Clean Air Excellence Award, the EPA recognized the Xact® 640 as an outstanding achievement in innovative clean air technology. The EPA also approved the Xact® 640 CEMS as an alternative method for periodic Method 29 testing and feed stream analysis, as well as for monitoring emissions during plant operation.

Features

- Automatic quality assurance, alarms, and control features
- Gas phase calibration not required
- Identification and measurement of as many as 19 elements simultaneously (refer to the periodic table on the Elements supported page of this data sheet)
- Internal calibration check incorporated with every sample analyzed
- Proven technology
- Daily, automatic upscale, blank, and flow checks
- Recognized by the EPA as an innovative clean air technology (Clean Air Excellence Award, 2007)
- Sampling, analysis, and near-real-time reporting (every 15, 30, 60 and 120 minutes)

Benefits

- Single monitor platform for Hg and HAP metals monitor compliance
- No PM monitor needed to comply with MATS
- May be used to meet 40 CFR Part 60 and 63 regulations
- Measures total mercury in $\mu\text{g}/\text{dscm}$
- Multi-metal analysis reduces expenses, time, and resources
- Non-destructive analysis allows for sample archiving
- Sensitive and reliable (ng/m^3 to $\mu\text{g}/\text{m}^3$ range)

Applications

The Xact® 640 monitoring system can simultaneously identify and measure multiple metals in flue gas to provide data for use in the following applications.

- Hg CEMS
- HAP metals CEMS
- Baselineing a new process
- Optimization of emission controls
- Permitting
- Regulatory compliance
- Risk management

Specifications

Measurement method.....	Based on EPA Method IO 3.3: Determination of Metals in Ambient PM Using XRF
Key applicable elements.....	Sb, As, Ba, Cd, Ca Cr, Co, Cu, Fe, Pb, Hg, Mn, Ni, Se, Ag, Sn, Ti, Tl, V, Zn, and more available
Measurement range	Demonstrated up to 1963 $\mu\text{g}/\text{dscm}$
Detection limits (IF, EPA IO - 3.3) ¹	Metal and sample time dependent; refer to the minimum detection limit (MDL) data
Sampling and analysis times.....	Every 15, 30, 60, 120 minutes, depending on the per sample mass
Calibration stability check frequency	Automatically with each sample analyzed
Estimated recalibration frequency	Annually, when manufacturer's operating recommendations are followed
Linearity	Correlation coefficient >0.99
Size and weight.....	19 inch w x 24 inch d x 19 inch h and 19 inch w x 24 inch d x 35 inch h 180 lbs 483 mm rack-mountable components
Required operating environment	Lab environment with temperature controlled to $20\pm 3^{\circ}\text{C}$ (68°F)
Power requirements ²	120 VAC/60 Hz @ 2-20 amp circuits 220 VAC/60 Hz 20 amp with an optional power converter
Options	All metals that the system is calibrated to measure will be reported Change or add elements Enclosures Remote control Remote polling

¹ Detection limits are determined using 95% confidence interference-free data.

² Power must be conditioned to maintain a factory warranty or service agreement.

Performance

Minimum Detection Limits ($\mu\text{g/dscm}$)

Sampling Time (min)

Element	Atomic Number	15	30	60	120
Cr	24	0.14	0.05	0.018	0.006
Mn	25	0.14	0.05	0.018	0.006
Fe	26	0.38	0.13	0.048	0.017
Co	27	0.16	0.06	0.020	0.007
Ni	28	0.11	0.04	0.014	0.005
Cu	29	0.13	0.05	0.017	0.006
Zn	30	0.12	0.04	0.014	0.005
Ga	31	0.05	0.02	0.007	0.002
Ge	32	0.06	0.02	0.008	0.003
As	33	0.06	0.02	0.007	0.003
Se	34	0.07	0.02	0.009	0.003
Ag	47	2.17	0.77	0.271	0.096
Cd	48	2.88	1.02	0.360	0.127
In	49	3.39	1.20	0.424	0.150
Sn	50	3.74	1.32	0.467	0.165
Sb	51	0.33	0.12	0.042	0.015
Ba	56	0.47	0.17	0.059	0.021
Hg	80	0.09	0.03	0.012	0.004
Tl	81	0.09	0.03	0.012	0.004
Pb	82	0.11	0.04	0.014	0.005
Bi	83	0.12	0.04	0.015	0.005

Interference Free, 1 Sigma

H																	He
Li	Be											B	C	N	O	F	Ne
Na	Mg											Al	Si	P	S	Cl	Ar
K	Ca	Sc	Ti	V	Cr	Mn	Fe	Co	Ni	Cu	Zn	Ga	Ge	As	Se	Br	Kr
Rb	Sr	Y	Zr	Nb	Mo	Tc	Ru	Rh	Pd	Ag	Cd	In	Sn	Sb	Te	I	Xe
Cs	Ba	*	Hf	Ta	W	Re	Os	Ir	Pt	Au	Hg	Tl	Pb	Bi	Po	At	Rn
Fr	Ra	**	Rf	Ha	Sg	Bh	Hs	Mt	Ds	Rg	Uub	Uut	Uuq	Uup	Uuh	Uus	Uuo
* Lanthanide Series			La	Ce	Pr	Nd	Pm	Sm	Eu	Gd	Tb	Dy	Ho	Er	Tm	Yb	Lu
** Actinide Series			Ac	Th	Pa	U	Np	Pu	Am	Cm	Bk	Cf	Es	Fm	Md	No	Lr

Elements Supported

Xact® 640 monitoring system identifies and measures the 63 elements highlighted in the table above. Minimum detection limits (MDLs) for the elements highlighted in blue can be found on the Performance page of this data sheet. The system is capable of measuring the elements highlighted in dark gray, but MDLs have not been developed.

Ordering Information

To place an order or for more information about the Xact® 640 continuous emissions monitoring system, contact your regional CES representative or email us at info@cooperenvironmental.com.

Sailbri Cooper Inc
 10300 SW Nimbus Ave.
 Suite P-B Tigard, Oregon 97223
 T: 503-670-8127 F: 503-624-2120
www.sci-monitoring.com